



## Instructions

Assembly of self-adhesive film strips  
**semaSORB PROBIRD DK400® Tape** on glass surface

### 1. Cut the strip

Number in the example: Glass width: 120cm / 5 = 24 strips.  
Length of the strips + 5 mm trim

### 2. Cleaning the glass surface

The glass surface is sprayed with a mixture of water, a dishwashing liquid and a little spirit and cleaned. Remove the glass surface with a rubber squeegee.

### 3. Creating the template

The first strip including silicone film can be applied as a template on the edge of the glass, with an adhesive strip at the top and bottom so fasten that it can be easily removed.

### 4. Wet the glass surface

Spray the glass surface with the assembly spray solution (1 liter of water + 1 tablespoon of assembly concentrate).

### 5. Remove the silicone film from the bird protection strips

Remove the silicone film from the bird protection strip with the aid of 2 adhesive strips and put it upside down on the glass. - The adhesive side shows to you. -

### 6. Assembly on the glass surface

Now spray the adhesive side and turn the strip over, lay it on the glass and completely wipe off the water with a soft squeegee (felt, rubber). Beginning from the top, then vertically down. If necessary repeat this process. Again and again, spray the outside of the film wet and only then the water out!

#### Note:

The glass surface should be very wet. The spray solution allows the bird protection strips to be pushed back and forth for a while until they are in the desired position.

When applying to plastic surfaces, it is essential to test at one point first!

### 7. Repeat steps 5 and 6

The next strip will be after a gap of 2.5cm (width of bird protection strips), etc., until all the strips are on the glass surface.

### 8. Cut bird protection strips to size

Carefully cut the strips on the frame with a cutter and make sure that the strips do not slip. Carefully absorb the remaining moisture along the window frame with a soft cloth / kitchen paper.  
The freshly applied stripes are sometimes still cloudy. This haze disappears within about 30 days after assembly. In cold seasons, this process can take longer.

### 3. Tips

semaSORB PROBIRD DK400 strips can be cleaned 30 days after installation with a window cleaner (except TFT, LCD monitor detergent) that does not contain abrasives. Do not use hard sponges, microfibre cloths, coarse cloths or brushes. Recommended are soft sponges, soft cloths or soft felt mixers. Never clean films dry.

The optimum temperature for the work is between 15 degrees Celsius and 25 degrees Celsius. Solar radiation heats the glass surface too much and should therefore be avoided during installation! If the disc is too hot, bubbles will form under the film, which can not be removed afterwards. Micro-dust causes the slightest bulges that are visible to the naked eye.

Therefore, pay attention to a thoroughly cleaned glass surface. Adhesive residues on the glass surface can be removed well with alcohol. Attention - Have good ventilation.